

Chapter 4: Quit a Game and Auto Switch OFF Table Lights

- Checkout with Cash.

Click **“Stop!”** icon to checkout > Select “cash” > click Square icon to checkout > collect cash from customer based on the rate shown in software.



- Checkout with Membership Card.

Click **“Stop!”** icon > Select “membership card” > click Square icon to checkout > enter membership card ID > Only enough credit membership ID able to check out > collect cash from customer based on the rate shown in software.



From:
<https://www.vyrox.com/wiki/> - **VYROX Wiki**

Permanent link:
https://www.vyrox.com/wiki/doku.php?id=quit_game&rev=1740986367

Last update: **2025/03/03 07:19**

